



SWAROVSKI

SWAROVSKI INFINITE CONTROL  
USER GUIDE 1.1



# SWAROVSKI

## SWAROVSKI INFINITE CONTROL

### GETTING STARTED

---

Welcome to Swarovski Lighting and the Infinite Aura Collection.  
This guide will provide instructions on how to control your lighting fixture with the proprietary Infinite Control App.

To ensure current user guide information, please visit Infinite Control Support  
at [www.swarovski-lighting.com/infinitecontrol](http://www.swarovski-lighting.com/infinitecontrol) or scan the QR code.



### WHAT'S IN THIS GUIDE

---

This guide explains how to set up the Infinite Control App and how to sync it with your lighting fixture.  
You will also learn how to add multiple fixtures, adjust the lighting temperature/brightness, invite additional users, and other tips and options.

- 3 Downloading and Setting Up the Infinite Control App
- 3 - 4 Registering Your First Lighting Fixture
- 4 - 5 How to Add Additional Lighting Fixtures to the App
- 5 How to Remove a Lighting Fixture from the App
- 6 How to Create and Save a Custom Aura
- 6 How to Delete a Custom Aura
- 6 How to Hide/Unhide Effects
- 7 How to Change the Name of the Lighting Fixture
- 7 How to Create a Group of Two or More Fixtures
- 8 How to Delete a Group
- 8 How to Invite Additional Users to Access the Lighting Fixture
- 9 How to Register an Additional User with an Invite Code
- 9 How to Update Your Account Settings
- 9 How to Change Your Password
- 10 How to Perform a Hard Reset on Your Fixture



# SWAROVSKI

## SWAROVSKI INFINITE CONTROL

### DOWNLOADING AND SETTING UP THE INFINITE CONTROL APP

---

BEGIN BY DOWNLOADING AND INSTALLING THE INFINITE CONTROL APP TO YOUR PHONE OR TABLET.

1. Find the Infinite Control App in one of the locations below, depending on your device.  
If you don't have an account with the Apple or Google Play stores, you must create one before you can download the app.
  - Apple App Store for iOS devices such as an iPhone or iPad.
  - Google Play Store for Android devices such as Samsung Galaxy s8 and Google Pixel.
2. Install the app. When the App is installed, open it and press **Register Product** to register your lighting fixture and pair it with your in-home WiFi network.

### REGISTERING YOUR FIRST LIGHTING FIXTURE

---

FOLLOW THESE STEPS TO ADD AND SYNC THE FIRST LIGHTING FIXTURE TO THE INFINITE CONTROL APP.

1. Locate the SSID number\* on the product tag that came with the fixture.
2. Enter the SSID number (8 Digit code located underneath the bar code).
3. Press **Continue** or enter on your keypad.
4. Press **Yes** if the correct product displays on the screen.
5. Enter your home WiFi network information.
6. Press **Continue**.
7. Press **Settings** and go to WiFi Settings to change your WiFi network to the fixture WiFi (SSID Number).
8. Return to the App. Your device will begin to pair with the fixture.
9. Wait for first green checkmark to illuminate.
10. Press **Settings** and go to WiFi Settings to change your WiFi network back to your home WiFi network.
11. Return to the App.



# SWAROVSKI

## SWAROVSKI INFINITE CONTROL

### REGISTERING YOUR FIRST LIGHTING FIXTURE (CONTINUED)

---

FOLLOW THESE STEPS TO ADD AND SYNC THE FIRST LIGHTING FIXTURE TO THE INFINITE CONTROL APP.

12. Wait for both green checkmarks to illuminate.
13. Press **Continue**.
14. Enter a name for your product.

\*THE SSID NUMBER FOR YOUR INDIVIDUAL FIXTURE IS LOCATED IN THE FOLLOWING LOCATIONS FOR YOUR CONVENIENCE:  
SOFT TAG ATTACHED TO FIXTURE, CANOPY LABEL, TRIM DIAGRAM.

### HOW TO ADD ADDITIONAL LIGHTING FIXTURES TO THE APP

---

ONCE YOU'VE ADDED YOUR FIRST FIXTURE, FOLLOW THESE STEPS TO ADD AND SYNC ADDITIONAL COMPATIBLE SWAROVSKI LIGHTING FIXTURES.

1. Open the Infinite Control app.
2. Press on the **Menu** icon at the top left corner of the screen.
3. Locate the SSID number on the product tag.
4. Press **Continue**.
5. Press **Yes** if the correct product displays on the screen.
6. Enter your home WiFi network information.
7. Press **Continue**.
8. Press **Settings** and go to WiFi Settings to change your WiFi network to the fixture WiFi (SSID Number).
9. Return to the App.
10. Wait for the first green check-mark to illuminate.
11. Press **Settings** and go to WiFi Settings to change your WiFi network back to your home WiFi network.



# SWAROVSKI

## SWAROVSKI INFINITE CONTROL

### HOW TO ADD ADDITIONAL LIGHTING FIXTURES TO THE APP (CONTINUED)

---

ONCE YOU'VE ADDED YOUR FIRST FIXTURE, FOLLOW THESE STEPS TO ADD AND SYNC ADDITIONAL COMPATIBLE SWAROVSKI LIGHTING FIXTURES.

12. Return to the App.
13. Wait for both green checkmarks to illuminate.
14. Press **Continue**.
15. Enter a name for your product.

### HOW TO REMOVE A LIGHTING FIXTURE FROM THE APP

---

IF YOUR PRODUCT HAS BEEN PROVISIONED TO AN ACCOUNT, YOU MUST ALSO REMOVE THE FIXTURE FROM THE APP.

1. Select **View All Fixtures** under **My Lighting Menu**.
2. Select the gear symbol by the fixture you would like to remove.
3. Select **Remove Fixture**.



# SWAROVSKI

## SWAROVSKI INFINITE CONTROL

### HOW TO CREATE AND SAVE A CUSTOM AURA

---

IN ADDITION TO THE PRE-SET AURAS THAT ARE PROGRAMMED ON THE FIXTURE, YOU HAVE THE OPTION TO CREATE YOUR OWN CUSTOM AURA BY CHOOSING THE BRIGHTNESS OF THE EFFECT LIGHT AND THE RING LIGHT.

1. Make sure you are on the fixture screen.
2. Move the **Effect Light** and **Ring Light** sliders to your preferred brightness.
3. The **Create Aura** button on the bottom of the screen will illuminate.
4. Press **Create Aura**.
5. Enter a name for your Custom Aura.
6. OPTIONAL: You may also add an image for your Custom Aura. Press the image at the top of the screen and follow the on-screen instructions.
7. Press **Continue**.

### HOW TO DELETE A CUSTOM AURA

---

ON THE APPLICABLE FIXTURE SCREEN PRESS AND HOLD THE CUSTOM AURA THAT YOU WISH TO DELETE.

1. A screen will appear: **Are you sure you want to delete this Custom Aura?**
2. Press **Yes**.

### HOW TO HIDE/UNHIDE EFFECTS

---

YOU HAVE THE OPTION TO HIDE/UNHIDE THE PRE-SET EFFECTS THAT COME STANDARD WITH THE LIGHTING FIXTURE.

1. With the Infinite Control App open, press on the **Menu** icon at the top left of the screen.
2. Press the toggle button next to **Show Effects** to hide or unhide Effects.



# SWAROVSKI

## SWAROVSKI INFINITE CONTROL

### HOW TO CHANGE THE NAME OF THE LIGHTING FIXTURE

---

YOU HAVE THE OPTION TO CHANGE THE NAME OF THE LIGHTING FIXTURE AT ANY TIME.

1. Press on the **Menu** icon at the top left corner of the screen.
2. Press **View All Fixtures** under the **My Lighting** section.
3. Press on the **Settings** icon on the top left of the product you wish to rename.
4. Change the name as desired.
5. Press **Update Name**.

### HOW TO CREATE A GROUP OF TWO OR MORE FIXTURES

---

YOU MAY GROUP TOGETHER TWO OR MORE FIXTURES FOR EASE OF CONTROLLING THE FIXTURES.

1. Open the Infinite Control App.
2. Press on the **Menu** icon at the top left of the screen.
3. Press **Add New Groups**.
4. Select the fixtures you wish to include in your Group.
5. Enter a custom name for your Group.
6. Press **Create Group**.
7. Press **Continue**.
8. Press **Menu** to see your groups under the **My Groups** section.



# SWAROVSKI

## SWAROVSKI INFINITE CONTROL

### HOW TO DELETE A GROUP

---

1. Open the Infinite Control App.
2. Press on the **Menu** icon at the top left of the screen.
3. Press **View All Groups** under the **My Groups** section.
4. Press on the **X** button on the top right of the group you wish to delete.
5. A screen will appear: **Are you sure you want to remove this fixture group?**
6. Press **Yes**.

### HOW TO INVITE ADDITIONAL USERS TO ACCESS THE LIGHTING FIXTURE

---

MULTIPLE USERS MAY CONTROL THE LIGHTING FIXTURE(S) SIMPLY BY DOWNLOADING AND INSTALLING THE INFINITE CONTROL APP ON THEIR PREFERRED IOS OR ANDROID DEVICE.

1. With the Infinite Control App open, press on the **Menu** icon located at the top left of the screen.
2. Press **Invite User**.
3. Enter the email address of the User you wish to invite to control your fixture(s).
4. Press **Continue**.
5. The designated User will receive an email with access instructions and an Invite Code.





# SWAROVSKI

## SWAROVSKI INFINITE CONTROL

### HOW TO REGISTER AN ADDITIONAL USER WITH AN INVITE CODE

---

1. The invited User must download and install the Infinite Control App on their device from the Apple App or Google Play store and create an account.
2. At the first screen, press **I Have An Invite Code**.
3. Enter the Invite Code found in the email received from Infinite Control.
4. Press **Continue**.
5. Follow the on-screen instructions to access the lighting fixture controls.

### HOW TO UPDATE YOUR ACCOUNT SETTINGS

---

1. With the Infinite Control App open, press on the **Menu** icon at the top left of the screen.
2. Press **Account Settings**.
3. Change information as desired.
4. Press on the **Menu** on the top left of the screen to view your updated information.

### HOW TO CHANGE YOUR PASSWORD

---

1. With the Infinite Control App open, press on the **Menu** icon at the top left of the screen.
2. Press **Account Settings**.
3. Scroll to the bottom of the screen.
4. Enter the new password.
5. Enter the new password again to confirm.
6. Press **Update Password**.



# SWAROVSKI

## SWAROVSKI INFINITE CONTROL

### HOW TO PERFORM A HARD RESET ON YOUR FIXTURE

---

IF YOUR FIXTURE IS NOT TRANSMITTING AN SSID SIGNAL, BECOMES UNRESPONSIVE TO THE INFINITE CONTROL APP, OR IF YOU WOULD LIKE TO REMOVE IT FROM YOUR INFINITE CONTROL ACCOUNT, A HARD RESET IS REQUIRED.

1. Ensure that the fixture power is on.
2. Locate the reset access port on the top of the Infinite Aura product.
3. Insert the reset tool (provided) into the port and press the internal reset button once.
4. Disconnect the power to the fixture to complete the reset process.

**NORTH AND  
SOUTH AMERICA**

Swarovski Lighting, Ltd.  
61 Industrial Boulevard  
Plattsburgh, New York 12901-1908  
USA  
Tel. +1 800 836 1892  
or +1 518 563 7500  
Fax +1 518 563 4228  
lighting.na@swarovski-lighting.com

**EUROPE**

Swarovski International Distribution AG  
Swarovski Lighting  
Dröschstrasse 15  
FL-9495 Triesen  
Principality of Liechtenstein  
Tel. +423 399 5656  
lighting.europe@swarovski.com

**AUSTRIA**

Tel. +43 5224 500 5656

**FRANCE**

Tel. +33 1 44 76 15 53

**GREAT BRITAIN**

Tel. +44 845 607 0341

**AFRICA / MIDDLE EAST / INDIA**

Swarovski Middle East FZE  
Swarovski Lighting  
P.O. Box 17128  
Jebel Ali Free Zone, Junction 6  
Dubai UAE  
Tel. +971 4 881 65 62  
lighting.me@swarovski.com  
lighting.india@swarovski.com

**AUSTRALIA / ASIA PACIFIC**

Swarovski Singapore Trading PTE LTD.  
Swarovski Lighting  
2 Alexandra Road  
Unit No. 03-01 Delta House  
159919, Singapore  
Tel: +65 6661 6393  
Email: lighting.ap@swarovski.com

Swarovski (Shanghai) Trading Co., Ltd.  
Swarovski Lighting  
Rm. 1601 No. 168 Xizang Rd(M),  
Shanghai, China  
Tel: +86 21 23069888  
Email: lighting.ap@swarovski.com